




How to Check the Software Version on Your Optovue System

NOTE: Although, the example below shows an Avanti System, this procedure is applicable to all Optovue products.

1. Launch the Optovue application.
2. On the top Menu, click on **Help**.
3. From the Help menu, click on **About**.



4. On the **About** window, look for the version number. Make note of the complete version.

